

ARAM BED AND BED PANEL



HSI853 Bed, left · H 450 mm, W 980 mm, Length 2040 mm

HSI854 Bed, right · H 450 mm, W 980 mm, Length 2040 mm

HSI855 Panel, left · H 600 mm, W 980 mm, D 20 mm, Length 2040 mm

HSI856 Panel, right · H 600 mm, W 980 mm, D 20 mm, Length 2040 mm

Colour: The product is available with laminate in ash or walnut. Other laminate finishes are available upon request.

Also available as: Vänster hörn, Vänster hörn + panel, Höger hörn, Höger hörn + panel

The Aram bed and bed panel are part of a furniture series developed for challenging environments. The series offers adaptable solutions for sleeping, studying, and storage, tailored to the specific needs of each facility.

- The bed and panel are securely fixed and highly durable, preventing loose parts that could be used as weapons and ensuring long-term use.
- The bed features fully enclosed sides and is mounted tightly against the wall and floor skirting to eliminate hiding places and enhance safety.
- A full-height protective panel prevents graffiti and creates a secluded, secure space.

The Aram bed and bed panel are particularly suitable for youth care, secure residential settings, and correctional environments.

Design: Healsafe Interiör Recommended placement: patient rooms

The bed features fully enclosed sides that extend down to the floor and is mounted flush against the wall and skirting. This design eliminates hiding spaces, protects against graffiti, and contributes to a safe and calm environment.

The full-size wall panel protects the wall surface, reduces wear, and enhances the sense of privacy and care.

To suit different room layouts, the bed is offered in two versions – one for left-hand corner placement and one for right-hand placement (viewed from the foot end). The same applies to the wall panel.

Matching [bedside tables, with or without compartments](#), are designed to complement each configuration.

The robust construction provides excellent stability, minimizes the risk of dismantling, and supports long-term durability.

The design language is carefully developed to create a calm and considered aesthetic.

The furniture is made from plywood – a strong and resilient material that ensures lasting performance.

The laminated surface is scratch-resistant, easy to clean, and retains its appearance over time.

Construction is based on traditional joinery and gluing methods, resulting in a strong and stable structure without visible hardware or detachable parts.

This increases both safety and durability over time.

The plywood edges are shaped with broad curves, creating rounded corners that reduce the risk of injury in case of a fall.

Secure mounting also prevents any parts from being removed or used as weapons.

The name Aram, derived from the Persian word for “calm,” reflects its geometric design language – in contrast to the sister series Roya, which features softer, more harmonious lines.

PRODUCT DATA

Material

Frame made of plywood with a laminated surface.

Sustainability

The product is made of plywood – a strong and durable material that ensures long service life. The laminated surface is scratch-resistant, easy to clean, and retains its appearance over time, making it a sustainable and practical choice for demanding environments. The plywood can be recycled as wood.

Warranty

The warranty period for our products made of laminated plywood with treated edges is 2 years from the date of delivery. During this period, the warranty covers any manufacturing defects, material flaws, and surface treatment issues. The warranty also applies to installation-related faults if the product has been installed by Healsafe Interior's appointed or in-house installers. The warranty covers the following areas:
Manufacturing defects: Any defects caused by faulty production or materials
Delamination: Separation of laminate layers due to adhesive or process failure
Surface treatment: Issues such as peeling, staining, or visual deterioration caused by faults in the treatment process

Installation

The bed is delivered assembled. The panel is delivered separately. We offer installation services for fixed interior furniture. Please let us know at the time of your inquiry, and we will assist in preparing a quote for this service. Installation is most commonly requested for larger projects. When you choose to use our installation service, we assume responsibility for the product warranty with regard to proper installation. If the product is installed by yourself or a third party, it is important to follow the installation instructions carefully and ensure proper assembly. The warranty does not apply if the product is not installed in accordance with the provided guidelines.

Maintenance

Clean the surface using a mild liquid detergent and a soft, clean cloth in circular motions. Rinse with clean water and dry with a soft cloth. For more persistent dirt, a soft nylon brush may be used in the same way. Alcohol-based disinfectants may be used on laminate surfaces when needed. Never use abrasive cleaners or coarse tools such as scouring pads, as these can scratch and damage the surface. Regularly check that all visible screws are securely tightened and that no gaps have formed.

Delivery

The furniture is tailored to each facility through a close and collaborative process with Healsafe Interiör. The pieces can be adapted to existing interiors, and a wide range of laminate finishes is available. Optional 3D visualization based on your room dimensions is offered upon request. Delivery time is 8–12 weeks from final order confirmation. Please note that unforeseen events may affect delivery schedules. For inquiries, please contact us at info@healsafeinterior.com

Manufacturing/Production

Sweden.