

ARAM MIRROR



HSI864 H 600 mm, W 380 mm, D 24 mm

HSI865 H 1160 mm, W 380 mm, D 24 mm

Colour: The product is available with laminate in ash or walnut. Other laminate options are available upon request.

Also available as: Spegel 1160 mm, Spegel 600 mm

The ligature resistant Aram mirror is part of an interior design series developed for challenging environments. The series offers adaptable solutions for sleeping, studying, and storage, tailored to the specific needs of each facility. The mirror combines high safety and functionality with an attractive appearance.

- Shatterproof and scratch-resistant polycarbonate mirror with minimal image distortion
- Beveled frame edges and tight wall fit to reduce ligature risk
- Replaceable mirror insert for easy servicing and extended product lifespan

The Aram mirror is particularly suitable for youth care, secure care environments, and correctional institutions, but is also ideal for any environment with elevated safety requirements. The mirror is made of scratch-resistant, unbreakable polycarbonate and provides a clear and natural reflection. High-quality image rendering is essential for supporting the user's self-esteem and wellbeing, by offering a reliable, distortion-free mirror image—especially important in challenging environments. The frame is made from durable plywood with a scratch-resistant laminated surface that is easy to clean and maintains its appearance over time. Beveled edges and the tight fit against the wall minimize potential anchor points, contributing to a safe and secure environment. The mirror insert is replaceable, making maintenance simple and ensuring long-term durability. Available in two sizes: 600 mm and 1160 mm in height, both 380 mm wide. The name Aram, derived from the Persian word for "calm," reflects a clear and geometric design language—contrasting with the sister series Roya, which features softer and more harmonious lines. The design is carefully considered and visually appealing, aiming to create safe and calming environments without visibly highlighting the safety features. Familiar interior accessories such as hook boards and mirrors are now available in both the Aram and Roya series. These complement the fixed furnishings and help create safe, functional, and aesthetically pleasing spaces where users and staff can feel secure.' Design: Healsafe Interiör Recommended placement: patient rooms or communal areas

PRODUCT DATA

Material

Frame made of plywood with a laminated surface. Mirror surface made of polycarbonate.

Maintenance

The surface of the frame should be cleaned with a mild liquid detergent and a soft, clean cloth using circular motions. Rinse with clean water and dry with a soft cloth. For more persistent dirt, a soft nylon brush may be used in the same manner. Alcohol-based disinfectants may be used on laminate surfaces if necessary. Never use abrasive cleaning agents or rough tools such as scouring pads, as they may scratch and damage the surface. Check regularly to ensure that all visible screws are properly tightened and that no gaps have formed. The mirror surface features a nano-treated coating that is resistant to chemicals and most acid attacks. Graffiti or other soiling can be removed using solvents or graffiti removers. Clean the mirror with a soft, clean cloth and a mild liquid detergent. Do not use abrasive chemicals or rough-surfaced sponges.

Sustainability

The product is made from plywood – a strong and durable material that ensures a long service life. The laminated surface is scratch-resistant, easy to clean, and retains its appearance over time – making it a sustainable and practical choice for demanding environments. If the mirror glass has got several scratches, the glass can be replaced with a replacement mirror glass that is ordered from Healsafe Interior. The plywood frame can be recycled as wood. The mirror surface can be recycled as hard plastic.

Warranty

The warranty period for our products made from laminated plywood with treated edges is 2 years from the delivery date. During this time, the warranty covers any manufacturing defects, material faults, and surface treatment issues. The warranty also covers installation-related faults when the product has been installed by Healsafe Interiör's appointed or in-house installers. The warranty covers the following areas:
Manufacturing defects: Any defects caused by production or material faults
Delamination: Separation of laminate layers due to faulty adhesive or process
Surface treatment: Defects such as peeling, staining, or deterioration in appearance due to treatment errors

Installation

The mirror is delivered assembled. The mirror is mounted with security screws. Make sure that the mirror is mounted on a flat wall surface to avoid gaps between the mirror and the wall. We offer installation services for fixed interior furniture. Please notify us at the time of your inquiry, and we will assist in preparing a quote for this service. Installation is most requested for larger projects. When you choose to use our installation service, we assume responsibility for the product warranty regarding correct installation. If you or a third party carry out the installation, it is important that the installation instructions are followed carefully, and the assembly is properly executed. The product warranty does not apply if the product is not installed according to the provided instructions.

Delivery

Delivery time is 8–12 weeks. Please note that unforeseen events may affect the delivery schedule. For inquiries, please contact us at info@healsafeinterior.com

Manufacturing/Production

Sweden.