

ORR PLUS ARMCHAIRS AND SOFAS



Colour: Aston is a durable faux leather textile (vinyl) with fluid-resistant and wipeable properties, making it ideal for environments with high hygiene and wear-resistance requirements. Highland features a woven texture that combines durability with a warm, homely feel. Both fabrics are well-suited for high-demand environments and cater to different needs. Both are available in a wide range of colours. [Aston \(link\)](#) & [Highland \(link\)](#).

Also available as: Orr PLUS fåtölj, Orr PLUS 2-sits soffa, Orr PLUS 3-sits soffa

Orr PLUS armchairs and sofas combine a reinforced structure with high comfort and practical functionality. With slim armrests that provide more seating space, the range is well suited to both small and large rooms. The neutral design makes the furniture easy to integrate into different environments, while safety and long-term durability remain at the forefront.

- Plywood reinforcement for extra strength and stability
- Fully enclosed base to prevent concealment
- Slim armrests maximises seating capacity

The Orr PLUS range is specifically designed for all environments with high safety requirements, such as psychiatric care, youth care, treatment centres and correctional facilities. Suitable for environments such as patient rooms, dayrooms, staff areas and communal spaces.

The frame is constructed from a combination of chipboard and plywood, reinforced with additional panels in the seat, back and underside to withstand daily stress and demanding use. Solid beech wood legs provide further stability. The enclosed base keeps the furniture safe and easy to clean.

Orr PLUS armchairs and sofas feature a timeless, neutral design reminiscent of a classic standard sofa. This understated style allows the furniture to blend seamlessly into most environments.

All seat and back cushions are removable, making cleaning simple and helping to maintain hygiene in demanding settings. The cushions are made from fire-retardant CMHR foam, combining comfort with safety for both users and staff.

The construction is free from piping, buttons and exposed staples, minimising the risk of self-harm, and security screws together with non-accessible staples are used to prevent misuse.

The gap between the base and the floor makes it quick and easy to clean around the furniture.

Orr PLUS has been tested for high loads, with the seat able to withstand a static weight of up to 500 kg. Thanks to its additional weight, the furniture remains firmly in place and is difficult to move or overturn, providing increased safety in high-risk environments.

An option to consider is the bariatric armchair available in the Orr PLUS range. This model is wider and additionally reinforced to withstand higher loads. With a seat width of 900 mm instead of 710 mm, it provides extra space and enhanced comfort where a larger seating area is required.

The range can be tailored to different interior concepts through a wide choice of fabrics and colours, with [Aston](#) or [Highland](#) textiles particularly recommended for optimal durability and aesthetics.

PRODUCT DATA

Material

Frame in reinforced plywood with solid wood legs. Fixed seat cushion in fire-retardant CMHR foam (combustion modified high resilience foam) and fully enclosed base. Construction free from piping, buttons and exposed details.

Sustainability

Orr PLUS is fire classified according to BS 7176:2007, source 5. The furniture has been strength and stability tested in accordance with BS EN 15373:2007, test level 3 for severe use, as well as BS 4875: Part 1:2007, test level 5 and BS EN 1022:2005. The seat and back have been statically load tested in accordance with EN 1728:2012, section 6.4, and the seat has also been tested to withstand a static weight load of up to 500 kg in accordance with EN 16139:2013. Fabrics are fire retardant according to CAL TB 116, 117 and NFPA 260 USA. Reupholstering furniture is a sustainable and cost-effective way to extend the product's lifespan. Contact us for guidance.

Warranty

7-year warranty covering any manufacturing defects (excluding upholstery). Specific terms apply to fabric warranty claims. See our Care Instructions

Assembling

Delivered fully assembled.

Maintenance

To maintain the condition of the sofa, we recommend cleaning it with a damp cloth and using mild cleaning agents if necessary. All materials are designed to be durable and easy to maintain, making them ideal for demanding environments. Surface disinfection can be used when required, but please note that frequent use may shorten the lifespan of the upholstery fabric. For more details, please refer to our Furniture Care Instructions. Technical Data HSP426: H 850 mm, W 710 mm, D 870 mm. Seat height: 440 mm. HSP427: H 850 mm, W 1240 mm, D 870 mm. Seat height: 440 mm. HSP428: H 850 mm, W 1770 mm, D 870 mm. Seat height: 440 mm. HSP429: H 850 mm, W 900 mm, D 870 mm. Seat height: 440 mm.

Delivery

Delivery time: 8–12 weeks. Please note that unforeseen events may affect the delivery schedule. For current delivery times at the point of order confirmation or prior to placing an order, please contact us at info@healsafeinterior.com

Manufacturing/Production

Europe