

J-TRAC CURTAIN RAIL SYSTEM – WALL MOUNTED



J-trac curtain rail – ceiling mounted, is a robust and suicide-resistant solution developed for environments with specific safety requirements, such as mental health care and correctional services. The curtain rail minimises the risk of the curtain or components becoming ligature points, while remaining durable and easy to handle.

- The runner releases under abnormal load to prevent the creation of ligature points
- Easy installation with security screws
- The rail and its components are securely fixed to the ceiling and very difficult to remove

The runners are made of elastic plastic and detach from the aluminium rail under abnormal load. This eliminates the risk of the curtain or runners being used as ligature points or weapons. The design allows staff to easily reattach the curtain. The runners have rounded edges and smooth surfaces to reduce the risk of injury if swallowed. To complement our J-trac curtain rails, we offer a carefully selected range of curtains: [Curtain Air](#), [Curtain Acoustic](#), [Curtain Dimout](#), and [Shower Curtain](#). Each comes with unique properties and colours, helping to soften sound, control light, and contribute to a thoughtful and harmonious environment. For guidance on measuring, placement, and more, please refer to the [Resources page](#). For technical details, see the Product Data section below. **Design:**

Healsafe Interior Quote cart: Quantity is in metres (1 = 1 metre). Please use the notes field at checkout to specify your request.

PRODUCT DATA

Maintenance

All components feature a smooth, hygienic surface that is easy to clean. For regular maintenance, simply wipe with a dry or damp clean cloth. Spills should be cleaned immediately using a soft, clean cloth or sponge dampened with warm, soapy water or a mild household detergent. After cleaning, wipe with a damp cloth to remove any residue, then dry with an absorbent paper towel or microfiber cloth for a streak-free finish.

Sustainability

The J-trac curtain rail and shower rail system is extremely robust and durable. The rail and end caps are recycled as metal. Runners are recycled as plastic. Life cycle analysis data is available on request.

Manufacturing/Production

Sweden

Technical data

All SKUs/Article number in the Assortment column to the right. Set JT-243 contains 2 end caps and 30 runners. Rail lengths are available up to 6100 mm. Custom lengths at additional cost. Rail wall: D 35 mm, H 58 mm. End cap wall: W 20 mm, D 37 mm H 109 mm. Standard colour: White. Release load: 12 runners bound together release at a maximum load of 4 kg. Appropriate number of runners per curtain is related to curtain size and weight. The product is patented and tested at RISE/SP in Sweden.

Delivery

Orders will be shipped within 6 weeks. For special orders, delivery times may vary. For questions, offers or order please contact: info@healsafeinterior.com.

Mounting instructions

Mounting instructions – J-trac curtain rail. Wall mounted (En)
Mounting instructions – J-trac curtain rail. Ceiling mounted (En)
Mounting instructions – J-trac shower rail 90° (En)

Measuring guides

Measuring guide Wall mounted (En) Measuring guide Wall mounted (Sv) Measuring guide Ceiling mounted (En) Measuring guide Ceiling mounted (Sv) Measuring guide Shower mounted (En) Measuring guide Shower mounted (Sv)

Runners

– Plastic (POM).

Mounting

Rail and end caps are tightly fixated with security screws to the wall. Mount the rail with security screws JT-283. Mounting instructions are to be followed to ensure correct function. (Please refer to the Resources page.)

Runners:

5 Years – Applies to normal use. Full warranty against manufacturing defects. (products which are manufactured in specially selected durable plastics, e.g. PU or POM, may be affected by extreme UV radiation, humidity, temperature, drastic change of temperature and/or humidity, however, not within normal indoor conditions, including bathroom environments. Nevertheless, aging occurs with all plastics, the durable plastics chosen by Healsafe Interior have properties where the aging process is, within normal conditions, very slow compared to many other plastics).

Rail and end cap

– Powder coated solid aluminium (powder coating gives a smooth and protective surface and is advisable in challenging environments).

Components for complete system

Rail End caps Countersunk security screws Runners Curtain hooks (or Eyelet hooks for shower curtain) Curtain

Rail and end caps:

Lifetime warranty – Applies to normal use. Full warranty against manufacturing defects.