

J-TRAC SHOWER RAIL SYSTEM



Also available as: 90° - 1450x1450 mm, 90° - 2000x2000 mm

J-trac shower rail, 90°, is a robust and suicide-resistant solution developed for environments with specific safety requirements, such as mental health care and correctional services. The curtain rail minimises the risk of the curtain or components becoming ligature points, while remaining durable and easy to handle.

- The runner releases under abnormal load to prevent the creation of ligature points
- Easy installation with security screws
- The rail and its components are securely fixed to the ceiling and very difficult to remove

J-trac shower rail, 90° is available in 2 standard sizes: 1450x1450 mm and 2000x2000 mm. Custom dimensions are available on request at an additional cost. The runners are made of elastic plastic and detach from the aluminium rail under abnormal load. This eliminates the risk of the curtain or runners being used as ligature points or weapons. The design allows staff to easily reattach the curtain. The runners have rounded edges and smooth surfaces to reduce the risk of injury if swallowed. To complement our J-trac shower rail, 90°, we offer a carefully selected range of shower curtains. Read more about options and benefits

<https://healsafeinterior.com/product/shower-curtain/>. For guidance on measuring, placement, and more, please refer to the [Resources page](#). For technical details, see the Product Data section below. **Design:** Healsafe Interior

PRODUCT DATA

Maintenance

All components feature a smooth, hygienic surface that is easy to clean. For regular maintenance, simply wipe with a dry or damp clean cloth. Spills should be cleaned immediately using a soft, clean cloth or sponge dampened with warm, soapy water or a mild household detergent. After cleaning, wipe with a damp cloth to remove any residue, then dry with an absorbent paper towel or microfiber cloth for a streak-free finish.

Sustainability

The J-trac curtain rail and shower rail are extremely robust and durable. The rail and end caps are recycled as metal. Runners are recycled as plastic. Life cycle analysis data is available on request.

Manufacturing/Production

Sweden

Technical data

JT 252: 1450x1450mm, rail dimensions. JT 262: 2000x2000mm, rail dimensions. The shower rail can be ordered in these standard sizes or in a custom size upon request (additional cost applies). See all SKUs/Article number in the Assortment column to the right. The 90° curvature has a 400mm radius. Set JT-244 contains 2 end caps and 25 runners. Rail ceiling & shower: D 26 mm, H 24 mm End cap ceiling: W 20 mm, D 70 mm H 27 mm Standard colour: White. Release load: 12 runners bound together release at a maximum load of 4 kg. Appropriate number of runners per curtain is related to curtain size and weight. The product is patented and tested at RISE/SP in Sweden.

Delivery

Orders will be shipped within 6 weeks. For special orders, delivery times may vary. For questions, offers or order please contact: info@healsafeinterior.com.

Mounting instructions

Mounting instructions – J-trac curtain rail. Wall mounted (En)
Mounting instructions – J-trac curtain rail. Ceiling mounted (En)
Mounting instructions – J-trac shower rail 90° (En)

Measuring guides

Measuring guide Wall mounted (En) Measuring guide Wall mounted (Sv) Measuring guide Ceiling mounted (En) Measuring guide Ceiling mounted (Sv) Measuring guide Shower mounted (En) Measuring guide Shower mounted (Sv)

Runners

– Plastic (POM).

Mounting

Rail and end caps are tightly fixated with security screws to the ceiling. Mount the rails with security screws JT-283. Mounting instructions are to be followed to ensure correct function. (Please refer to the Resources page.)

Runners:

5 Years – Applies to normal use. Full warranty against manufacturing defects. (Products which are manufactured in specially selected durable plastics, e.g. PU or POM, may be affected by extreme UV radiation, humidity, temperature, drastic change of temperature and/or humidity, however, not within normal indoor conditions, including bathroom environments. Nevertheless, aging occurs with all plastics, the durable plastics chosen by Healsafe Interior have properties where the aging process is, within normal conditions, very slow compared to many other plastics).

Rail and end cap

– Powder coated solid aluminium (powder coating gives a smooth and protective surface and is advisable in challenging environments).

Components for complete system

Rail End caps Countersunk security screws Runners Eyelet hooks Shower curtain

Rails and end caps:

Lifetime warranty – Applies to normal use. Full warranty against manufacturing defects.