

BOLD CHAIR, SEAT PAD



HSP525 H 790 mm, W 520 mm, D 500 mm, Seat height 450 mm · Weight 5.8 kg

Colour: Chair: Alpine White, Moonwalk Grey, Cool Green. Seat cushion: Grey.

Durable chair with a fixed, water-repellent foam seat, designed to offer both comfort and safety in high-security environments such as psychiatric care and correctional facilities. Built to last and withstand long-term use.

- Durable construction with fixed sled bases for increased stability, built to withstand long-term, intensive use.
- Lightweight and stackable design makes it easy to handle and store.
- Water-repellent surface that is hygienic and easy to clean.

The Bold chair is suitable for psychiatric care, youth care, correctional facilities and other settings where furniture must withstand intensive use without compromising on safety or function. Bold chair is a comfortable and lightweight chair with a fixed foam seat, moulded in one piece for maximum durability and low weight. It can be stacked up to six chairs high, making it easy to move and store. The robust design, including fixed sled bases that connect the legs, creates a stable structure that reduces the risk of injury, self-harm or the chair being used as a weapon. Bold contributes to a safe environment where security and comfort go hand in hand. The chair is available in three colours – white (Alpine white), light grey (Moonwalk grey) and green (Cool green) – with a solid grey seat cushion. Suitable for placement in communal rooms, patient rooms and shared spaces such as dining areas.

PRODUCT DATA

Material

100% polypropylene with additives that significantly enhance impact resistance and compressive strength.

Sustainability

Strength and stability tested for non-domestic environments (BS EN 16139:2013 – Level 2). Static seat load tested up to 300 kg (EN728:2012, Section 6.4). Bold chairs are built for long-term use. At the end of their lifecycle, the chairs can be ground into powder and repurposed into new products. Fully recyclable as plastic.

Warranty

7 years – valid under normal use. Full warranty covering manufacturing defects.

Assembly

No assembly required.

Maintenance

The wipeable surface is easy to clean using a soft cloth. We recommend using cleaning wipes, mild detergents, degreasers or antibacterial cleaning agents. Avoid abrasive materials, steam cleaning, or pressure washing. Use bleach and chlorine-based disinfectants with caution. Do not place the chair near heat sources.

Delivery

Delivery time: 8–12 weeks. Please note that unforeseen circumstances may affect delivery times. For the most up-to-date delivery information, please contact us at info@healsafeinterior.com before placing an order or upon order confirmation.

Manufacturing/Production

Europe.